

# AEROQUIP® E-Z CLIP ASSEMBLY INSTRUCTIONS

## Cut the Hose

Cut the hose to proper length with an appropriate cutting tool. Aeroquip's hand-held cutter (79R8930) has been specially designed for cutting all non-wire reinforced hose. Be sure the cut is made square to the hose length.



## Slip Two Clips on the Hose

Slide two clips (be sure to use the correct size) onto the cut end of the hose. The orientation of the clips does not affect the performance of the connection. However, for ease of assembly, both clips should be oriented in the same direction. NOTE: If you don't slide the clips over the hose at this time, you will have to stretch the clips over the hose and fitting later. This may permanently damage the clip.



## Oil the Nipple

Lubricate the nipple with a generous amount of the refrigeration or A/C system's compressor lubricating oil. This MUST be done to lower the force of nipple insertion.



## Insert the Nipple into the Hose

Insert the nipple into the hose. To ensure that the nipple is fully inserted, check the gap between the cut end of the hose and the shoulder of the nipple. Care should be taken to avoid kinking or other damage to the hose during this step. NOTE: Be sure to wipe excess oil from the nipple and hose.



## Snap on the Cage

Snap the cage into the groove on the nipple. The arms of the cage should extend over the hose-covered length of nipple. When the cage has been correctly installed in the cage groove, the cage will be able to rotate in the groove. This step MUST be performed to ensure that:

1. The clips will be located over the O-Rings on the nipple.
2. The connection will be compatible with the connection's pressure rating.



## Position the Clips

Slide the clips over the cage arms and into the channels on each arm of the cage.



## Close the Clips


Using the Connecting Tool (79R8920) to close the clips. The tool should be positioned squarely on the clip connection points and should remain square as pressure is applied and the clip is closed.



CORRECT

INCORRECT

The nose of the plier should be firmly seated under the assembly bump and lock latch. If the pliers are not kept square as you close the clip, the clasp may have an offset. Use the pliers to correct the clasp alignment.



INCORRECT

CORRECT

NOTE: E-Z Clip components should not be reused.

