



Technical Service Warning:

When replacing Freightliner Cascadia and Coronado Radiators, the correct length bolts must be used when mounting the charge air cooler, rock guard (if equipped) and surge tank.

The CAC, Charge Air Cooler, has three mounting bolts the same length and one longer bolt with rubber spacers (see pictures below).

The Surge Tank has one bolt that mounts through the radiator frame and a spacer that must be used.

Failure to carefully install the bolts/washers/spacers properly can cause the bolt to go through the frame and damage the side plate on the radiator. This places stress on the adjacent tube and will result in the tube failing.

Failure to install correctly can result in one of these issues happening. Unfortunately these are not covered by warranty!

