

1. Remove existing thermostatic switch.
2. Drill hole larger with 7/16" drill bit.
3. Install new thermostatic switch and insert capillary tube in evaporator next to the existing electronic probe.

